

MEASURING AN ACUTE DIE: AMERICAN PRECISION

Use the Theoretical Sharp dimensions to calculate tonnage and minimum flange for acute dies.

