


HP DURABLADE® E STATION PARTING TOOLS

Cat. No. 5627 — Guide Unit Assembly includes:

1, 2, 3, 4, 5, 6, 7, 8, 9

Cat. No. 5728 — Spring Pack Assembly includes:

19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30



	DESCRIPTION	CAT. NO.
1	Stripper Clip	5521
2	Guide Stripper Ring	5538
3	Spring	971694
4	Wave Spring	8155
5	Locking Button	5519
6	Special Pin	5522
7	Guide Unit Only	5632
8	Socket Head Cap Screw [M5 x 13.39mm]	5210
9	Lifter Button	5209
10	Set Screw [M6 x 8mm]	6298
11	Bushing	5631
12	Punch Holder with Bushing	5628
13	Punch Holder Key	1862
14	Lock Washer	2112
15	Socket Head Cap Screw [M5 x 12mm]	6110
16	Disc Spring	971690
17	Socket Head Cap Screw [M12 x 55mm]	6026
18	Anti Lock Shim	5413
19	Retaining Ring	5747
20	Spring Support	5741
21	Spring Cover	5679
22	Disc Spring (7 required)	5449
23	Adjustment Shaft	5739
24	Wave Spring	971692
25	Driver	5742
26	Spring	972396
27	Adjustment Locking Ball	972420
28	Adjustment Button	5737
29	Retaining Ring	972441
30	O-Ring	972430